





Modelo DC



Open: The normally open Automatic Drip Check drains accumulated water/fluid from condensation/system leakage from the piping.



Closed: When the system piping suddenly fills with water/fluid the Automatic Drip Check closes.

Dimensions

